


Model browser tree on the left side of the interface.

- eva 96 hacioglu1863653r
- Drawing Resources
- Sheet: 1
 - Default Border
 - ISO
 - VIEW1:hacioglu1
 - VIEW4:hacioglu1

Main drawing area showing a technical drawing of a mold assembly. The drawing includes a top view of a mold with a circular feature and a side view of a mold with a complex profile. A red arrow points from the 'Styles Editor' tab in the ribbon to a white callout box.

Select Manage ribbon and then click on "Styles Editor" tab



Drop the list of options of dimension option and select Default (ISO)

In the Units Dialog select the precision for linear and angular dimensions. If the tolerance of dimension fully determines the decimal part then show the integer part of dimensions. If it is the case select 0.0 precision

Place Views Annotate Tools Man

Update Update Copied Properties

fx Parameters

Model

- eva 96 hacioglu1863653r
- Drawing Resources
- Sheet: 1
 - Default Border
 - ISO
 - VIEW1:hacioglu1
 - VIEW4:hacioglu1

Style and Standard Editor [Library - Read Only]

Back New... Save Reset Local Styles

Dimension Style [Default (ISO)]

Units Alternate Units Display Text Tolerance Options Notes and Leaders

Line Type: By Layer

Weight: By Layer Color: [Color Icon]

Terminator: Filled

Size (X): 3 Height (Y): 1.00 mm

Internal Chain Terminator: Small Dot

A: Extension 3.18 mm


B: Origin Offset 2.00 mm

C: Gap 1.00 mm

D: Spacing 8.00 mm

E: Part Offset 10.00 mm

Import Done



Software interface showing a tree view of drawing resources and model components. The tree includes:

- Model
 - eva 96 hacioglu1863653r
 - Drawing Resources
 - Sheet: 1
 - Default Border
 - ISO
 - VIEW1:hacioglu1
 - VIEW4:hacioglu1

Style and Standard Editor [Library - Read Only]

Standard

- Default Standard (ISO)
- Balloon
- Center Mark
- Datum Target
- Dimension
 - Default - Method 1b (ISO)
 - Default - Method 2a (ISO)
 - Default - Method 2b (ISO)
 - Default - mm [in] (ISO)
 - Default (ISO)
- Feature Control Frame
- Hatch
- Hole Table
- ID
- Layers
- Leader
- Object Defaults
- Parts List
- Revision Table
- Surface Texture
- Table
- Text
 - Label Text (ISO)
 - Note Text (ISO)
 - View Annotation
- Weld Symbol
- Weld Bead

Text Styles [Note Text (ISO)]

Paragraph Settings

Spacing	Value	% Stretch	Color
[Icon]	1.000 cm	100	[Color]

Justifications: [Icons]

Rotation: [Icons]

Character Formatting

Font: Arial | Text Height: 3.50 mm (dropdown menu open showing 2.50 mm, 3.50 mm, 5.00 mm, 7.00 mm, 10.00 mm, 14.00 mm, 20.00 mm) | Bold (B) | Italic (I) | Underline (U) | Italicize Symbols (checked)

Comments: [Text Area]

Buttons: Back, New..., Save, Reset, Local Styles, Import, Done

Partial view of another software window showing a tree view with items like 'eamline' and 'Supplier Content'.

